

Storm Area Light Installation Guide

WARNING:

- THE PRODUCT MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN.
- THE POWER SUPPLY MUST BE TURNED OFF BEFORE INSTALLATION.
- NO WARRANTY WILL BE ACCEPTED IF THIS PRODUCT IS NOT INSTALLED BY A QUALIFIED ELECTRICIAN.
- THE LIGHT SOURCE CONTAINED IN THIS LUMINAIRE SHALL ONLY BE REPLACED BY THE MANUFACTURER OR HIS SERVICE AGENT OR A SIMILAR QUALIFIED PERSON.
- THE DRIVER CAN'T BE REPLACED.
- WHEN PRODUCTS ARE INSTALLED IN HIGH WIND ENVIRONMENTS, APPROPRIATE INSTALLATION/ FASTENING METHODS MUST BE APPLIED SO THAT THE PRODUCT MOUNTING POINTS ARE NOT DAMAGED DUE TO VIBRATION, MOVEMENT OR CORROSION.
- GOOD PRACTICE DOES NOT RECOMMEND CONTINUOUS USE WITHOUT APPROPRIATE SWITCHING CYCLES.















Product Specification

Model	Wattage (W)	Color Temp (K)	Initial Lumens (Im)	Voltage (V)	Frequency (Hz)	Ta (°⊂)	PF	Net Weight (g)	Size(mm) a*b*c	Beam Angle
ELHL-PLA-PD3 75W	75	4000/5000	11250	220-240~	50/60	50	0.9	3150	428*247*55	120°
ELHL-PLA-PD3 100W	100	4000/5000	15000	220-240~	50/60	50	0.9	3250	428*247*55	120°
ELHL-PLA-PD3 150W	150	4000/5000	22500	220-240~	50/60	50	0.9	3450	428*247*55	120°
ELHL-PLA-PD3 200W	200	4000/5000	30000	220-240~	50/60	50	0.9	4200	458*268*55	120°




Installation Options


Pole Mount




Surface Mount



Daylight Photocell Sensor



Fitting Dimensions



Optional Accessories

Order Code	ELA Part No.	Model No.	Note		
463069	463069	ELHL-PLA-PB	Photocell		
463079	463079	ELHL-PLA-SFA	Slip Fitter A		
463119	463119	ELHL-PLA-U1	U bracket F 75W-150W		
463129	463129	ELHL-PLA-U2	U bracket F 200W		

Energetic Lighting Australia Pty Ltd Unit 1, 350 Edgar Street, Condell Park, Sydney, NSW, 2200, Australia Tel: 1300215598 E-mail: info@energeticlighting.com.au Web: energeticlighting.com.au